




CLOCKWORK  
COMPONENTS

# How To Measure

OKE5012-180/330

Where to measure



Aug 2022



CLOCKWORK COMPONENTS LTD.  
T : 01993 775 767 F : 01993 892 313 E: sales@clockworkcomponents.com  
www.clockworkcomponents.com

All images, photos, text and designs are protected by copyright and may be subject to additional Design Right Protection