

# Suprema Ottoman 1215 Power Low Leg 1211 Power High Leg













### **Power Ottoman Extension, Steamlined Legrest-Only Motion Furniture Mechanism**

The Suprema Ottoman™ is a perfect fit for furniture within leg heights of 2" (50.8 mm) to 6" (152.4 mm with flipper ottoman). The new, generously extended ottoman can accommodate an additional 2" (50.8 mm) of leg support.













SEAT CUSHION WIDTH REFERENCE CHART					
ORDERING DASH	SEAT CUSHION WIDTH				
	INCHES	METRIC			
1	20 1/4	514.40			
2	21 1/4	539.80			
3	22 1/4	565.20			
4	22 3/4	577.90			
5	23 3/8	593.70			
6	24 1/4	616			
7	25 1/4	641.40			
8	27 7/8	708.00			
9	28 3/4	730.30			
10	30 7/16	773.10			
11	31	787.40			
12	33 3/4	857.30			



### **Test Report**

Test Date	Test Report No.	Test Performed by	Title/ Part No.	Starting Date	Completion Date	
2019/07/12	LPCN19046-01	Alice Chen Yao	Suprema Ottoman Only(1215) Life Cycle Test	2019/06/21	2019/07/06	
То	Gavin Guo,Rita Ma and Antoflow Pan					
From	China Furniture Hardware Division Testing Centre					

### **Purpose/History:**

To evaluate the performance and durability of the Suprema Ottoman Only 1215(Using the Limoss Motor (MD125-88-L1-372-219)), we conducted a life cycle test on the sample of Suprema Ottoman Only. Leggett and Platt Test Procedure "25,000-Cycle, 36.4lbs load Life Test" was used for this test.

### **Set up/Procedures:**

- 1.To install the Suprema Ottoman Only sample onto testing setup;
- 2.To place the load onto the sample as per Leggett and Platt Test Procedure;

Load Position	Back	Seat	Footrest
Weight	0Kg(0Lbs)	0Kg(0Lbs)	16.5Kg(36.4Lbs)

3.To record the cycles by the counter.

#### Data:

Data recorded throughout the tested resulted in an extended-footrest drop (from wear) of 0.17" (4.4mm), but within acceptable limits.

#### **Results:**

This mechanism completed the 25,000-cyle life test without abnormal noises, wear or any loss of function. See the sample after test from the below Picture 1.



## **Test Report**

### **Conclusion:**

Per this procedure, Suprema Ottoman Only mechanism(Using the Limoss Motor (MD125-88-L1-372-219)) passed the "25,000-cycle 36.4lbs" life test as per the Leggett & Platt Test Standard.

### **Pictures:**



Picture 1: Sample after Test

### Other Remarks:

# Suprema Ottoman Low Leg



### Width measurement for fitting



